

Diagnostic solutions

KTS 250



A QUICK, MOBILE ALL-IN-ONE DIAGNOSTIC TOOL FOR THE WORKSHOP AND ON THE ROAD – POWERFUL, COMPACT AND ROBUST



BENEFITS OF KTS 250 AT A GLANCE

- ▶ **Fast:** ready to use within seconds
- ▶ **Modern, simple and intuitive operation for all diagnostic work on the vehicle**
- ▶ **Lightning-fast** and **best in class** vehicle system overview (ECU and DTC)
- ▶ **Automatic vehicle identification** through **best VIN database** by Bosch
- ▶ **Online updates** directly and without any compromises
- ▶ **Plug & Play** – online licensing: just enter your username and password and off you go!
- ▶ Perfect vehicle coverage thanks to integrated ESI[tronic] diagnostic database

KTS 250 is the perfect all-in-one tool for vehicle reception, diagnosis and service in every workshop

Diagnostic solutions KTS 250

DIAGNOSIS AT ITS BEST

Use the latest and advanced diagnostic data for passenger car and van systems for all necessary diagnostic tasks

Automated and ultra-fast vehicle scan delivering built-in ECUs and stored trouble codes in a handy overview

Delete all faults with one click

Flight recorder function for detecting and analyzing complex intermittent faults

Protocols for documenting and handing information about the vehicle provided to customers

Advanced coding and adjustment features

Reliable and future-proof thanks to Ethernet / Diagnosis over IP (DoIP) as future diagnostic protocol

Service task menu for timesaving operation - execute all service-relevant operations **within seconds** such as

- ▶ Battery replacement
- ▶ Service interval reset
- ▶ Head light adjustment
- ▶ Particulate filter regeneration
- ▶ Tyre-pressure-sensor replacement and many more...

Worldwide outstanding coverage for all control units such as

- ▶ Engine control
- ▶ ABS / ESP
- ▶ Airbag
- ▶ Air conditioning system
- ▶ Central electronics
- ▶ Tyre control systems
- ▶ Parking brake and many more...

Including the most important features such as

- ▶ ECU Identification
- ▶ Reading/deleting error memory
- ▶ Actual values
- ▶ Actuators
- ▶ Function tests
- ▶ Adjustments / settings
- ▶ Special functions for service procedures

Available as accessory:

Vehicle-specific adapters for diagnosis of older vehicles

 **Order number 0 684 400 260**



Technical Data

Android™ Processor-Platform	Processor: i.MX6Q (Quad Core) @1.2 GHz Storage: 16 GB SSD Memory: 2 GB RAM Operating system: Android™ (AOSP) 6.0.1
Battery	Lithium Ion 7.2 V / 2600 mAh
Display Size	7" / Resolution: 1024 x 600
Software	“Chronium” browser for web browsing Printing option
Interfaces	WLAN 802.11 b/g/n USB 2.0 LAN 10/100 MBit

Scope of delivery

- KTS 250 Tester
- OBD cable
- Power supply
- USB cable
- Manual
- Carrying case



Where can I find more information about diagnostic solutions...?

Bosch Workshop World
<http://www.bosch-workshop-world.com>

YouTube channel
<https://www.youtube.com/channel/UCX35lpVGym534NmQoXF8cZw>

 **GENERALDIAGNOSTIC**
SPECIALIST AUTOMOTIVE MEASUREMENT AND TEST

01455 617 888
www.generaldiagnostic.co.uk