

ADVANCED DIAGNOSTIC TECHNOLOGY – IN ONE COMPACT DEVICE



BENEFITS OF THE KTS 350 AT A GLANCE

- ▶ Mobile all-round solution: control unit diagnosis, troubleshooting, repair and maintenance
- ▶ Support of all current and future vehicle interfaces based on Ethernet, in parallel operation of several BUS systems
- ▶ PassThru interface for programming the control units on the portals of the vehicle manufacturer as per Euro 5/6
- ▶ Plug & play through the pre-installed and configured application ESI[tronic] 2.0
- ▶ Quick system start and efficient working thanks to the improved processor and modern SSD technology
- ▶ Regular online updates available
- ▶ Windows 10 operating system allows easy installation of additional applications

Diagnostic Solutions KTS 350

TIME SAVING

ready to use in only 45 seconds

With an improved processor and state-of-the-art SSD technology, the KTS 350 complies with high technology standards. From the start of the device to the opening of the ESI[tronic] 2.0 software, only a few seconds elapse therefore saving the workshop time and effort.



FUTURE READY

up to 100 times faster data transfer

The KTS 350 has an integrated Ethernet interface which allows you to transfer data up to 100 times faster compared to the previous CAN technology. Invest in the future with this modern and durable technology.

Technical Data

Processor	Intel® Celeron® N3160 1.6 (2.24) GHz, Quad Core
RAM	4 GB DDR3
Memory	256 GB SSD
Display	10.1" TFT Touchscreen, Display resolution 1024 x 600
Battery	Lithium Ion. 5200 mAh @7.2V
Wireless	Bluetooth 2.1 Power class 1, WLAN IEEE 802.11 b/g/n
Interface	2 x USB 3.0, LAN 10/100 Mbit, VGA, Audio
Operating system	Windows 10 IoT
Weight	Approx. 2 kg
Dimensions	361 x 222 x 49 mm
External DVD drive	Yes
OBD connection cable	1.8 m

Scope of delivery (0 684 400 350)

Diagnostic tester unit KTS 350 with touch pen

External DVD-drive, Recovery DVD

OBD connection cable

Battery & power supply

Operating manual

Case

Subject to technical and program changes.

Where do I find more information about diagnostic solutions...?



Bosch Workshop World

www.bosch-workshopworld.co.uk

YouTube Channel

<https://www.youtube.com/user/BoschAutoPartsUK>

General Diagnostic
23 Woodland Road
Hinckley
Leicestershire
LE10 1JF
www.generaldiagnostic.co.uk



BOSCH
Invented for life

